


Temperaturføler Temperaturgivare Temperature sensor



- N** Tilkoblingsveiledning
- S** Anslutningsanvisning
- E** Connection Instructions


ART.NR.:
11156

CS 60




N Funksjon S Funktion E Function	Kode Kod Code	Tilkobling (se figur) Anslutning (se figur) Connection (see figure)
Tilluftsføler Temperaturgivare, tilluft Temperature sensor, supply air	B1	P5-1 / P5-2
Avtrekksføler Temperaturgivare, frånluft Temperature sensor, extract air	B3	P7-1 / P7-2
Uteluftsføler Temperaturgivare, uteluft Temperature sensor, outdoor air	B4	P7-3 / P7-4


CS 50 / CS 500



N Funksjon S Funktion E Function	Kode Kod Code	Tilkobling (se figur) Anslutning (se figur) Connection (see figure)
Tilluftsføler Temperaturgivare, tilluft Temperature sensor	B1	J5-1 J5-2

SP 30 / SP 40



N Funksjon S Funktion E Function	Kode Kod Code	Tilkobling (se figur) Anslutning (se figur) Connection (see figure)
Tilluftsføler Temperaturgivare, tilluft Temperature sensor	B1	T2 



Flexit AS, Televeien 15, N-1870 Ørje www.flexit.no